




Xiegu X6100 Wi-Fi & Bluetooth Function Instructions

WiFi Operation Instructions



SCAN button: Scan for nearby Wi-Fi / hotspots (Access Point)

CONNECT/DISCONNECT: Connect/disconnect the hotspot in the left list.

EDIT: Edit the element selected by the orange box on the right.

CONFIG: Move the orange box to the next.

EXIT: Exit the interface.


1. **SYSTEM SETTING** – **WLAN** – press **MFK** knob to enter the Wi-Fi setting interface



2. Select a Wi-Fi to connect by rotating **MFK** – press **CONFIG**



3. Press **CONFIG** to move to password – press **EDIT** to pop up the digital keyboard




4. Enter/delete password by rotating & press **MFK** knob



5. Click **ENTER** by rotating & press **MFK** knob to confirm password (important)



6. Press **EDIT** to exit the digital keyboard




7. Press **CONNECT**, please wait for about 10s



8. WiFi connected!



9. Press **EXIT** to exit the Wi-Fi interface




10. Wi-Fi connected confirmed!





Bluetooth Operation Instructions



Operation Instructions

OFF/ON: Turn on/off the built-in Bluetooth function.

CONNECT/DISCONNECT: Connect/disconnect the selected Bluetooth device on the left.

EXIT: Exit the interface.

Note: When the built-in Bluetooth function is displayed as "ON", it will always scan the surrounding Bluetooth devices.


1. **SYSTEM SETTING** – **WLAN** – press **MFK** knob to enter the Bluetooth setting interface (for the first time, it should take about 1 minute to scan Bluetooth device, please be patient; will be 5s only from second time.)



2. Select a Bluetooth device by rotating **MFK** – press **CONNECT** to connect (please make sure your Bluetooth device is on)



3. Bluetooth connected!



4. Press **EXIT** to exit the Wi-Fi interface

